



Hard-Lining the Main Cylinder

Written By: Brianna Kufa

Step 1 — Hard-Lining the Main Cylinder

- Remove the couplers and hex nipples at the elbow using a wrench.
- Tighten the hoses (with thread tape) into the elbows.

This document was last generated on 2012-10-31 11:36:08 AM.